



JTHOMPSON TOPS

Custom Solid Wood Surfaces ★ EST 1982

1198 Carter Rd
Sandy Ridge, NC 27046
Phone: 877-595-7105

Email: sales@jthompsonstops.com
www.jthompsonstops.com

MINERAL OIL & BEESWAX FINISH

Solid wood countertops with a mineral oil finish will give many years of natural wood beauty when maintained properly. Our recommendation is that you use **Howard's Butcherblock Conditioner** to maintain your wood top.

Warranty

J. Thompson Tops Inc. is proud to provide our customers with quality solid wood tops. Customized to serve your special requirements and for this purpose will stand behind our work. Our products are warranted against any manufacturing error, but cannot be warranted against locations of excessive humidity or extreme dryness, both of which are beyond our control. J Thompson Tops Inc reserves the right to qualify any claims against our products. Such as improper installation or failure to care for properly.

Most important

Do not use water to clean solid wood tops until you create an accomplished mineral oil finish. Regular applications of mineral oil (weekly) should be done to build up the finish. This will insure the wood does not get dry. This process may take several months depending on your climate. Cleaning should be done with a dry cloth. If you must clean with water, dry top immediately and apply mineral oil. Once you have accomplished the finish, you will be able to use a damp cloth to clean. As with any wood surface never allow water to stay on top at anytime. Even with a seasoned oil finish prolonged exposure will raise the wood grain, making surface rough. If you do raise the grain, the rough surface can be sanded back to smooth. Depending on amount of roughness, begin sanding using an orbital/electric sander with 120 grit sandpaper, then 180 grit and 220 grit. re-apply mineral oil.

Warranty and Installation instructions

J. Thompson Tops Inc since 1982, is proud to provide its customers with quality solid wood tops that are customized to serve your special requirements and for this purpose will stand behind our work. Our products are warranted against any manufacturing error, but cannot be warranted against locations of excessive humidity or extreme dryness, both of which are beyond our control, failure or care to properly install the top, or the abusive handling of the top. J Thompson Tops Inc reserves the right to qualify any claims against our product. Proper installation is required for full warranty of countertops. Tops especially island tops extra wide and thick ect should have special care in attaching to cabinets. Be sure to screw down tops every 8 to 10" around all sides, corners, and center sections, using # 8 self drilling screws. Tops that are 3 ½ feet or more should have third row of attaching screws in the middle of the top. For ease of installation, pre-drill cabinets with 1/8" pilot bit on an angle to the inside of cabinet. Prestart screws before setting the top on the cabinets. Overhangs or more than 12" should be supported every 12 to 24" with corbels or steel supports. Care should be taken in keeping the top, once installed, from experiencing radical moisture swings. Watch door being left open for long periods of time(letting extra moisture enter the environment), and also watch space heaters close to the top(drying out environment). In new construction, mineral oil finish tops must be kept wrapped in plastic and with a protective product(cardboard, Styrofoam sheets) until the HVAC is in operation. This will ensure the top remains stable and protected. Special finish tops must be covered with non scratching material(rosen paper) and protective covering. Always leave owner our standard care sheet.