



# **JTHOMPSON TOPS**

*Custom Solid Wood Surfaces* ★ EST 1982

1198 Carter Rd  
Sandy Ridge, NC 27046  
Phone: 877-595-7105

Email: [sales@jthompsonstops.com](mailto:sales@jthompsonstops.com)  
[www.jthompsonstops.com](http://www.jthompsonstops.com)

## **Rubio Monocoat Finish**

As with any finished wood product, protecting the finish is most important to the longevity of your solid wood top. We recommend that you use a mild all-purpose cleaner for general cleaning and disinfecting, such as Mrs. Meyers All-Purpose Cleaner. Rubio Monocoat Soap or Rubio Monocoat Surface Care Spray can also be purchased and used up to once a week for a deeper clean, Please avoid frequent soap and water as this will lead to wearing of the finish.

## **Warranty**

J. Thompson Tops Inc, since 1982, is proud to provide its customers with quality solid wood tops. Customized to serve your special requirements, and for this purpose will stand behind our work. Our products are warranted against any manufacturing error, but cannot be warranted against locations of excessive humidity or extreme dryness, both of which are beyond our control. J Thompson Tops Inc reserves the right to qualify any claims against our product. Such as improper installation or failure to care for properly.

## **Installation Instructions**

Proper installation is required for full warranty of countertops. Tops, especially island tops extra wide and thick ect. should have special care in attaching to cabinets. Be sure to screw down tops every 8 to 10 inches around all sides, corners, and center sections using #8 self drilling screws. Tops that are 3 ½ feet or more should have a third row of attaching screws in the middle of the top. For ease of installation, pre-drill cabinets with a 1/8" pilot bit on an angle to the inside of cabinet. Pre-start screws before setting the top on the cabinets. Overhangs of more than 12 inches should be supported every 12 to 24" with corbels or steel supports. Care should be taken in keeping the top, once installed from experiencing radical moisture swings. Watch doors being left open for long periods of time( letting extra moisture enter the environment), and also watch for space heaters close to the top( drying out environment). In new construction, mineral oil finish tops must be kept wrapped in plastic and with a protective product( cardboard, Styrofoam sheets). This will ensure the top remains stable and protected. Special finish tops must be covered with non scratching material(rosen paper) and protective covering. Always leave the owner our standard care sheet.